

# PlymoVent Starter SA-24



© Copyright. All rights reserved.

*With the PlymoVent Starter SA-24 you can operate the fan and lamp cartridge from a switch at the extractor hood.*

## **PLYMOVENT CORP**

375 Raritan Center Parkway, Edison, N.J. 08837, USA  
Tel. (732) 417-0808, Fax (732) 417-1818  
[www.plymovent.com](http://www.plymovent.com), [info@plymoventusa.com](mailto:info@plymoventusa.com)

## **PLYMOVENT CANADA INC**

6615 Ordan Dr, Unit #3, Mississauga, Ont. L5T 1X2, Canada  
Tel. (905) 564-4748, Fax (905) 564-4609  
[www.plymovent.com](http://www.plymovent.com), [info@plymovent.ca](mailto:info@plymovent.ca)

**PLYMOVENT®**  
**INTELLIGENT PROCESS VENTILATION™**

# PlymoVent Starter SA-24

The starter is supplied to be used with one extractor with a light in its hood and one fan. The starter is mounted to the wall, supplied with A.C. and connected to the extractor fan. It comes complete with switch assembly for the hood, 30 ft/ 10 m of cable, built-in contactor and 24 V/75W transformer, which operates the fan contactor and the lamp cartridge in the hood of the extractor.

- Increases the use of the extractor. The fan start/stop switch and the lamp switch are always close to operator, therefore convenient to use.
  - Energy saving. The operator can quickly and easily stop the fan.
  - SA-24 makes the electrical installation simple.
- Must be fitted with relevant motor overload.

**Prod. no. SA-24/75 or SA-24/75-2.**



*PlymoVent offers you a clean working environment at the right price.*

## TECHNICAL DATA

### Prod. no. SA-24/75

For one extractor with one fan. Complete with switch assembly.

#### Power input:

115/208/230/460/575 V

**Transformer:** 75 W-24 V for one halogen lamp cartridge HL-20/24. The transformer also controls the built-in contactor. The contactor must be fitted with relevant motor overload (not included).


**Motor overloads:** Overloads for installation inside electrical control boxes like ES-90, M-1000, SA-24 and control boxes for wall mounted filters.

#### Prod. no:


**MS-1.0/2.9** Overload, 1.0-2.9 Amp.

**MS-3.7/12.0** Overload, 3.7-12.0 Amp.

**MS-12.0/32.0** Overload, 12.0-32.0 Amp.



Starter SA-24/75-2 connected to two extractors (PlymoVent LM-2) with one fan and with lights in the hoods of the extractors.



Starter SA-24/75 in connection with PlymoVent Extractor Crane UK-4516 with halogen lamp cartridge HL-20/24 in hood and FUK-1800 fan.